

OBJEDNACÍ DATA PRO SQ 0214

	SQ 0214	E	L	2	2	2	2
TYPE SQ 0214	_____						
VOLTAGE INPUTS	_____						
A - 57V B - 63V C - 100V D - 110V E - 230V F - 400V G - 500V							
TYPE OF CONNECTION	_____						
L - Phase to Phase N - Phase to Neutral							
OUTPUT RELAY	_____						
1 - impulse 100ms 2 - impulse 300ms 3 - adjustable impulse (100ms <x<1000ms) 4 - continual impulse 0 - without relay							
DEAD BUSBAR FUNCTION	_____						
0 - none 1 - 10% Un 2 - 20% Un 3 - 30% Un 4 - 40% Un							
STATUS OUTPUT (ship version option)	_____						
0 - none S - status relay							
DELTA PHI SETTING	_____						
0 - default value +/- 2..20 el. V - setting range +2..20 el. U - setting range -2..20 el.							